

Special antenna bases

146 – 174 / 400 – 470 MHz

These antenna bases are suitable for the whip K 50 56 20 1 (Ord. No. 510 322).
Connector M11 x 1

Manufacturer	Model	Type No.	(Ord. No.)
Audi 80	Sedan 8/86 – 11/94	K 70 81 23 03²⁾	(510 188)
Audi 80 Avant	Station wagon 6/92 – 1/96	728 184²⁾	(510 025)
Audi 80 B 4	Convertible from 3/91	K 70 81 23 03²⁾	(510 188)
Audi 100	Sedan 9/82 – 12/90	K 70 81 23 03²⁾	(510 188)
Audi 100 Avant	Station wagon 12/90 – 6/94	K 70 81 23 03²⁾	(510 188)
Audi A 4	Sedan from 11/94	K 70 81 23 03²⁾	(510 188)
Audi A 6	Sedan from 6/94	K 70 81 23 03²⁾	(510 188)
BMW E 23	7 Series up to 9/86	K 70 81 23 03²⁾	(510 188) or 724 712²⁾ (510 015)
BMW E 24	6 Series	K 70 81 23 03²⁾	(510 188) or 724 712²⁾ (510 015)
BMW E 28	5 Series up to 2/88	K 70 81 23 03²⁾	(510 188) or 724 712²⁾ (510 015)
BMW E 30	3 Series Sedan 11/82 – 12/90	K 70 81 23 03²⁾	(510 188) or 724 712²⁾ (510 015)
BMW E 30/C	3 Series cabrio	K 70 81 23 03²⁾	(510 188)
BMW E 31	8 Series from `90	725 040²⁾	(510 014)
BMW E 32	7 Series 9/86 – 6/94	725 040¹⁾	(510 014)
BMW E 34	5 Series 2/88 – 11/95	732 701¹⁾	(510 139)
BMW E 34/2	5 Series touring 9/91 – 2/97	733 838¹⁾	(510 222)
BMW E 36/C	Convertible 4/93 – 3/00	K 70 81 23 03²⁾	(510 188)
BWM E 36/2	3 Series coupé 1/92 – 3/99	K 70 81 23 03²⁾	(510 188) or 724 712²⁾ (510 015)
BMW E 36/3	3 Series touring 6/95 – 9/99	733 838¹⁾	(510 222)
BMW E 36/4	3 Series Sedan from 12/90 – 4/98	K 70 81 23 03²⁾	(510 188) or 724 712²⁾ (510 015)
BMW E 38	7 Series from 7/94	736 222¹⁾	(510 248)
BMW E 39	5 Series from 12/95	736 222¹⁾	(510 248)
Ford Mondeo	Notchback 1/93 – 8/00	728 184²⁾	(510 025)
Ford Mondeo	Fastback 2/93 – 8/00	728 184²⁾	(510 025)
Ford Mondeo	Station wagon from 2/93 – 8/00	728 184²⁾	(510 025)
Ford Scorpio	Sedan 4/85 – 1/95	K 70 81 23 03²⁾	(510 188)
Ford Scorpio	Station wagon 9/91 – 1/95	728 184²⁾	(510 025)
Mercedes W 124	200 – 500 Sedan 1/85 – 6/95	725 080¹⁾	(510 017)
Mercedes C 124	200 – 300 Coupé 1/85 – 5/96	725 086¹⁾	(510 018)
Mercedes A 124	200 – 300 Convertible 1/85 – 5/96	732 307¹⁾	(510 019)
Mercedes S 124	200 – 300 model T 9/85 – 5/96	725 188¹⁾	(510 020)
Mercedes W 140	S class Sedan 5/91 – 10/98	728 947¹⁾	(510 022)
Mercedes C 140	S class Coupé from 10/92	731 324¹⁾	(510 023)
Mercedes R 129	SL Convertible from 9/89	726 436¹⁾	(510 024)
Mercedes W 201	Model 190 11/82 – 5/93	725 084¹⁾	(510 016)
Mercedes W 202	C class 6/93 – 5/00	731 326¹⁾	(510 219)
Mercedes W 126	S class Sedan 10/79 – 5/91	725 082¹⁾	(510 021)
Mercedes S 123	Model T	725 188¹⁾	(510 020)
Mercedes W 210	E class ab 7/95	736 836¹⁾	(510 254)
Opel Vectra A	Notchback 6/88 – 9/95	728 184²⁾	(510 025)
Opel Vectra A	Fastback 3/89 – 9/95	728 184²⁾	(510 025)
Opel Vectra B	from 9/95	K 70 81 23 03²⁾	(510 188)
Opel Omega A	Sedan 9/86 – 3/94	728 184²⁾	(510 025)
Opel Omega A	Station wagon 9/86 – 3/94	728 184²⁾	(510 025)
Opel Calibra	from 3/90	728 184¹⁾	(510 025)
Opel Astra A	Fastback 9/91 – 2/98	728 184¹⁾	(510 025)
Opel Astra A	Notchback 9/91 – 2/98	K 70 81 23 03²⁾	(510 188)
Opel Astra A	Convertible 3/93 – 2/99	725 082²⁾	(510 021)
Opel Senator B	Sedan	730 896²⁾	(510 026)
VW Passat III	Sedan 2/88 – 7/96	726 930²⁾	(510 027)
Vehicles	with mounting surfaces that are inclined at approx. 45°	728 184²⁾	(510 025)

1) for mounting into the factory-produced bore hole, without subsequent work. 2) if there is no bore hole.