


## UFS 601 Firmware transfer


Preparation:

- Connect receiver and PC using the connection cable
- Switch receiver ON


1. Open the programm „downloader.exe“
2. You will see the following window:



- First select the bookmark „Application“.
  - o In this the COM Port to be used is set.




3. Now select the bookmark „Application“.



Now select the key „Browse“


4. The firmware „ufs601\_tng-v01.43“ is now selected and opened



5. Now select the key „Open“

8. Now click on the key „Upload“

- Firmware loading will now be initiated



9. When firmware uploading has been completed, you will see the report as shown in the picture above

10. Finally pull the mains plug and then re-insert it (mains reset).

Firmware updating has now been completed. The connection cable can now be removed.