

## Guide for Software and Channel List Updating

Image files (.img) are available for both the software and the channel list update process. These can be installed via the USB 2.0 interface on the rear panel of the unit.

- Please set up the directory „kathrein/ufs902“ on your USB stick, and then copy into this the software file „\*.img“ and the channel list „\*.img“ (\* Name the file)

**Note: the USB stick must be formatted FAT/FAT32.**

- switch off the UFS 902 (Power switch OFF)
- insert the USB stick
- press down the key TV/R on the receiver's front panel and hold this down
- switch the UFS 902 on (power switch ON)
- keep the TV/R key still pressed down
- after a short time you will see displayed "Emergency Boot" and shortly afterwards „Update“
- if the receiver has found the files for the update, then you will see displayed „Update Cnt x“ (x stands for the number of update files found)

**Note: if „Update Cnt x“ is not displayed, but rather e.g.. NO FOLDER, then simply hold down the TV/R key longer to start the update procedure anew.**

- now one can release the TV/R key
- the receiver will now start the update -> in the display will appear „x ER yy“ or x WR yy
- x is the number of the update file
- yy is in percent
- lafter the updates have been carried out the UFS 902 starts up again independantly
- Now one can remove the USB stick